| Decrept                                | 70°F<br>(21°C) | 140°F<br>(60°C) | 212°F<br>(100°C) | Dagwart                     | 70°F<br>(21°C) | 140°F<br>(60°C) | 212°F<br>(100°C |  |
|--|----------------|-----------------|------------------|-----------------------------|----------------|-----------------|-----------------|--|
| Reagent                                | (21 0)         | (00 C)          | (100 C)          | Reagent                     |                |                 |                 |  |
| A                                      |                |                 |                  | Barium sulfide<br>Beer      | S<br>S         | S<br>S          | S               |  |
| Acetic acid (10%)                      | S              | S               |                  | Beet Juice                  | S              | S               | 0               |  |
| Acetic acid (50%)                      | S              | S               | 0                | Benzaldehyde                | S              | S               | O               |  |
| Acetic acid (100%)                     | S              | S               | · ·              | Benzene                     | 0              | U               | U               |  |
| Acetic acid (100%) Acetic anhydride    | S              | S               |                  | Benezene Sulfonic Acid, 10% | S              | S               | S               |  |
| Acetone                                | S              | S               |                  | Benzoic Acid                | S              | O               | O               |  |
| Acetonitrile                           | S              | 3               |                  | Benzyl alcohol              | S              | S               |                 |  |
| Acetophenone                           | 0              | 0               | U                | Benzyl chloride             | S              | S               |                 |  |
| Almond Oil                             | S              | S               | O                | Bismuth carbonate           | S              | S               |                 |  |
| Allinona Oil Aluminum ammonium sulfate | S              | S               |                  | Bluing                      | S              | S               | S               |  |
| Aluminum chloride                      | S              | S               | 0                | Borax                       | S              | S               | S               |  |
| Aluminum fluoride                      | S              | S               | J                | Boric acid                  | S              | S               | _               |  |
| Aluminum hydroxide                     | S              | S               |                  | Brandy                      | S              | S               |                 |  |
| Aluminum nyaroxide Aluminum nitrate    | S              | S               | S                | Brake fluid                 | S              | 0               |                 |  |
|  |                |                 | 3                | Brine                       | S              | S               | S               |  |
| Aluminum potassium sulfate             | S<br>S         | S<br>S          |                  | Bromic acid                 | U              | U               | _               |  |
| Alums (all types)                      |                |                 |                  | Bromine                     | U              | U               |                 |  |
| Ammonia (anhydrous)                    | S              | S               |                  | Bromine water               | Ü              | U               |                 |  |
| Ammonia (30% aqueous)                  | S              | S               |                  | Butane                      | 0              |                 |                 |  |
| Ammonium bi-fluoride                   | S              | S               |                  | Butyl acetate               | Ü              | U               |                 |  |
| Ammonium carbonate                     | S              | S               | S                | Butyl acrylate              | Ü              | Ü               |                 |  |
| Ammonium chloride                      | S              | S               | 0                | Butyl alcohol               | S              | S               |                 |  |
| Ammonium fluoride (25%)                | S              | S               |                  | Butyl Phthalate             | S              | S               | S               |  |
| Ammonium hydroxide                     | S              | S               |                  | C                           |                |                 |                 |  |
| Ammonium nitrate                       | S              | S               | S                | Calcium bisulfate           | S              | S               |                 |  |
| Ammonium sulfate                       | S              | S               | S                | Calcium carbonate           | S              | S               | S               |  |
| Ammonium sulfide                       | S              | S               |                  | Calcium chlorate            | S              | S               | _               |  |
| Ammonium thiocyanate                   | S              | S               |                  | Calcium chloride            | S              | S               | 0               |  |
| Amyl acetate                           | 0              | U               |                  | Calcium hydroxide           | S              | S               | S               |  |
| Amyl alcohol                           | S              | 0               | U                | Calcium hypoclorite         | S              | S               | -               |  |
| Amyl chloride                          | U              | U               |                  | Calcium nitrate             | S              | S               |                 |  |
| Aniline                                | S              | S               | Ο                | Calcium soap grease         | S              | 0               |                 |  |
| Anisole                                | 0              | 0               | U                | Calcium sulfate             | S              | S               |                 |  |
| Antimony trichloride                   | S              | S               |                  | Calgonite (1%)              | S              | S               |                 |  |
| Apple Juice                            | S              | S               | S                | Camphor Oil                 | U              | U               | U               |  |
| Aqua regia                             | 0              | 0               |                  | Carbon dioxide (dry)        | S              | S               |                 |  |
| Arsenic acid                           | S              | S               |                  | Carbon dioxide (wet)        | S              | S               |                 |  |
| Aviation fuel                          | 0              | 0               |                  | Carbon disulfide            | 0              | U               |                 |  |
| В                                      |                |                 |                  | Carbon monoxide             | S              | S               |                 |  |
| Barium carbonate                       | S              | S               |                  | Carbon tetrachloride        | U              | U               |                 |  |
| Barium chloride                        | S              | S               | 0                | Carbonic acid               | S              | S               |                 |  |
| Barium hydroxide                       | S              | S               |                  | Castor oil                  | S              | S               |                 |  |
| Barium soap grease                     | S              | 0               |                  | Caustic Soda, conc.         | S              | S               | S               |  |
| Barium sulfate                         | S              | S               |                  | Cellosolve                  | S              | S               |                 |  |

Legend: S = Satisfactory O = Some attack U = Unsatisfactory 1 of 5



| Reagent  | 70°F<br>(21°C)        | 140°F<br>(60°C)            | 212°F<br>(100°C) | Reagent  | 70°F<br>(21°C)   | 140°F<br>(60°C)                | 212°F<br>(100°C) |
|--|-----------------------|----------------------------|------------------|--|--|--------------------------------|------------------|
| Cetyl alcohol  | S                     | -                          | -                | Ethylene chloride  | U  | U                              | -                |
| Chlorine (dry)   | Ū                     | U                          |                  | Ethylene chlorohydrin  | S  | S                              |                  |
| Chlorine (wet)   | 0                     | U                          |                  | Ethylene dichloride  | S  |                                |                  |
| Chloroacetic acid  | S                     |                            |                  | Ethylene glycol  | S  | S                              |                  |
| Chlorobenzene  | Ü                     | U                          |                  | Ethylene oxide   | S  |                                |                  |
| Chloroform   | 0                     | U                          |                  | F  |  |                                |                  |
| Chlorosulfonic acid  | Ü                     | U                          |                  | Ferric chloride  | S  | S                              |                  |
| Chromic acid (10%)   | S                     | S                          |                  | Ferric nitrate   | S  | S                              |                  |
| Chromic acid (50%)   | S                     | S                          |                  | Ferric sulfate   | S  | S                              |                  |
| Chromic acid (80%)   | S                     | Ū                          |                  | Ferrous chloride   | S  | S                              |                  |
| Cider  | S                     | S                          |                  | Ferrous nitrate  | S  | S                              | 0                |
| Citric acid  | S                     | S                          |                  | Ferrous sulfate  | S  | S                              | Ü                |
| Clorox   | S                     | S                          | S                | Fluorine   | U  | U                              |                  |
| Clove Oil  | 0                     | U                          | U                | Fluosilicic acid   | S  | S                              |                  |
| Copper chloride  | S                     | S                          | O                | Formaldehyde   | S  | S                              | 0                |
| Copper cyanide   | S                     | S                          |                  | Formic acid (10%)  | S  | S                              | O                |
|  | S                     | S                          |                  | ` ,  |  | 3                              |                  |
| Copper fluoride  |                       |                            |                  | Formic acid (100%)   | S  |                                |                  |
| Copper nitrate   | S                     | S                          |                  | Freon (12, 22)   | U  | C                              |                  |
| Copper sulfate   | S                     | S                          |                  | Fructose   | S  | S                              |                  |
| Corn oil   | S                     | S                          |                  | Fruit juice  | S  | S                              |                  |
| Cottonseed oil   | S                     | S                          |                  | Fuel oil   | 0  | 0                              |                  |
| Cresol   | S                     | S                          |                  | Furfural   | U  | U                              |                  |
| Cuprous chloride   | S                     | S                          |                  | G  |  |                                |                  |
| Cyclohexane  | S                     | 0                          |                  | Gasoline   | 0  | U                              |                  |
| Cyclohexanol   | S                     | 0                          |                  | Gelatin  | S  | S                              |                  |
| Cyclohexanone  | 0                     | U                          |                  | Glucose  | S  | S                              | _                |
| D  |                       |                            |                  | Glycerol   | S  | S                              | S                |
| Decalin  | U                     | U                          |                  | Glycol   | S  | S                              | 0                |
| Developers (photographic)  | S                     | S                          |                  | Glycolic acid  | S  | S                              |                  |
| Dextrin  | S                     | S                          |                  | Н  |  |                                |                  |
| Dibutyl phthalate  | S                     | S                          |                  | Heptane  | U  | U                              | U                |
| Dichloroethylene   | S                     |                            |                  | Hexadecyl alcohol  | S  | S                              |                  |
|  |                       |                            |                  |  | _  | U                              |                  |
| Diethanolamine   | S                     | S                          |                  | Hexane   | 0  | U                              |                  |
| Diethyl ether  | S<br>O                | 0                          |                  | Hydrobromic acid (50%)   | S  | S                              |                  |
|  |                       |                            |                  |  |  |                                | 0                |
| Diethyl ether  | 0                     | 0                          |                  | Hydrobromic acid (50%)   | S  | S                              | 0                |
| Diethyl ether<br>Diglycolic acid   | O<br>S                | O<br>S                     |                  | Hydrobromic acid (50%)<br>Hydrochloric acid (20%)  | S<br>S   | S<br>S                         |                  |
| Diethyl ether Diglycolic acid Diisooctyl phthalate   | O<br>S<br>S           | O<br>S<br>S                | U                | Hydrobromic acid (50%)<br>Hydrochloric acid (20%)<br>Hydrochloric acid (100%)  | S<br>S<br>S  | S<br>S<br>S                    |                  |
| Diethyl ether Diglycolic acid Diisooctyl phthalate Dimethyl phthalate  | O<br>S<br>S<br>S      | O<br>S<br>S<br>S           | U                | Hydrobromic acid (50%)<br>Hydrochloric acid (20%)<br>Hydrochloric acid (100%)<br>Hydrofluoric acid (35%)   | \$<br>\$<br>\$<br>\$                                     | \$<br>\$<br>\$<br>O            |                  |
| Diethyl ether Diglycolic acid Diisooctyl phthalate Dimethyl phthalate Dioctyl Phthalate  | O<br>S<br>S<br>S<br>U | O<br>S<br>S<br>S<br>U      | U                | Hydrobromic acid (50%) Hydrochloric acid (20%) Hydrochloric acid (100%) Hydrofluoric acid (35%) Hydrogen chloride gas (dry)  | \$<br>\$<br>\$<br>\$<br>\$                               | \$<br>\$<br>\$<br>\$<br>\$     |                  |
| Diethyl ether Diglycolic acid Diisooctyl phthalate Dimethyl phthalate Dioctyl Phthalate p-Dioxane  | O<br>S<br>S<br>S<br>U | O<br>S<br>S<br>S<br>U      | U                | Hydrobromic acid (50%) Hydrochloric acid (20%) Hydrochloric acid (100%) Hydrofluoric acid (35%) Hydrogen chloride gas (dry) Hydrogen peroxide (30%)  | S S S S S S  | s<br>s<br>s<br>o<br>s<br>o     | 0                |
| Diethyl ether Diglycolic acid Diisooctyl phthalate Dimethyl phthalate Dioctyl Phthalate p-Dioxane E  | O<br>S<br>S<br>U<br>S | O<br>S<br>S<br>S<br>U<br>O | U                | Hydrobromic acid (50%) Hydrochloric acid (20%) Hydrochloric acid (100%) Hydrofluoric acid (35%) Hydrogen chloride gas (dry) Hydrogen peroxide (30%) Hydrogen peroxide (90%)                                  | \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ | \$<br>\$<br>\$<br>0<br>\$<br>0 | 0                |
| Diethyl ether Diglycolic acid Diisooctyl phthalate Dimethyl phthalate Dioctyl Phthalate p-Dioxane  E Ethanolamine Ethyl acetate              | O S S S U S S         | O S S S U O S              | U                | Hydrobromic acid (50%) Hydrochloric acid (20%) Hydrochloric acid (100%) Hydrofluoric acid (35%) Hydrogen chloride gas (dry) Hydrogen peroxide (30%) Hydrogen peroxide (90%) Hydrogen sulfide                 | s<br>s<br>s<br>s<br>s<br>o<br>s                          | \$<br>\$<br>0<br>\$<br>0<br>\$ | 0                |
| Diethyl ether Diglycolic acid Diisooctyl phthalate Dimethyl phthalate Dioctyl Phthalate p-Dioxane E Ethanolamine Ethyl acetate Ethyl alcohol | O S S S U S S S       | O S S S U O S S S S S      |                  | Hydrobromic acid (50%) Hydrochloric acid (20%) Hydrochloric acid (100%) Hydrofluoric acid (35%) Hydrogen chloride gas (dry) Hydrogen peroxide (30%) Hydrogen peroxide (90%) Hydrogen sulfide Hydroiodic acid | \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ | \$ \$ \$ 0 \$ 0 0 \$ U         | 0                |
| Diethyl ether Diglycolic acid Diisooctyl phthalate Dimethyl phthalate Dioctyl Phthalate p-Dioxane  E Ethanolamine Ethyl acetate              | O S S S S S S S S     | O S S S U O S S S          |                  | Hydrobromic acid (50%) Hydrochloric acid (20%) Hydrochloric acid (100%) Hydrofluoric acid (35%) Hydrogen chloride gas (dry) Hydrogen peroxide (30%) Hydrogen peroxide (90%) Hydrogen sulfide Hydroiodic acid | \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ | \$ \$ \$ 0 \$ 0 0 \$ U         | 0                |

Legend: S = Satisfactory O = Some attack U = Unsatisfactory 2 of 5



|                          | 70°F   | 140°F  | 212°F   |  | 70°F   | 140°F  |  |
|--------------------------|--------|--------|---------|--|--------|--------|--|
| Reagent                  | (21°C) | (60°C) | (100°C) | Reagent                                | (21°C) | (60°C) |  |
| odine (dry)              | S      | S      |         | Motor oil                              | S      | S      |  |
| odine (wet)              | U      |        |         | Mustard Paste                          | S      |        |  |
| sooctane                 | U      |        |         | N                                      |        |        |  |
| Isopropyl alcohol        | S      | S      |         | Naphtha                                | S      | S      |  |
| J                        |        |        |         | Naphthalene                            | S      | S      |  |
| Jet fuel (JP-4 and JP-5) | 0      | U      |         | Neat's Foot Oil                        | S      |        |  |
| K                        |        |        |         | Nickel chloride                        | S      | S      |  |
| Kerosene                 | 0      | U      |         | Nickel nitrate                         | S      | S      |  |
| _                        |        |        |         | Nickel sulfate                         | S      | S      |  |
| _actic acid              | S      | S      |         | Nitric acid (10%)                      | S      | S      |  |
| Lacquer                  | S      |        |         | Nitric acid, conc.                     | 0      | Ū      |  |
| _anolin                  | S      | S      |         | Nitric acid (fuming)                   | U      |        |  |
| Lead acetate             | S      | S      | S       | Nitric/sulfuric acid (50/50)           | U      |        |  |
| Lemon oil                | 0      | _      | -       | Nitrobenzene                           | S      | 0      |  |
| igroin                   | S      |        |         | Nitrous acid                           | 0      | J      |  |
| ∟igroi⊓<br>∟ime Sulfur   | S      |        |         | Nutmeg Oil                             | U      | U      |  |
| ime Sullur<br>inseed oil | S      | S      |         | Nutmeg Oil O                           | U      | U      |  |
|                          |        | 0      |         |  | C      | C      |  |
| Lubricating oil          | S      | O      |         | Oleic acid                             | S      | S      |  |
| _ye                      | S      |        |         | Oleum                                  | U      | 0      |  |
| M                        |        |        |         | Olive oil                              | S      | S      |  |
| Magnesium carbonate      | S      | S      | S       | Orange Juice                           | S      | _      |  |
| Magnesium chloride       | S      | S      | 0       | Oxalic acid                            | S      | S      |  |
| Magnesium hydroxide      | S      | S      | S       | Oxygen                                 | U      | U      |  |
| Magnesium nitrate        | S      | S      |         | Ozone                                  | U      | U      |  |
| Magnesium sulfate        | S      | S      |         | P                                      |        |        |  |
| Magnesium sulfite        | S      | S      |         | Palmitic Acid                          | S      | S      |  |
| Malic acid               | S      | 0      |         | Paradichlorobenzene                    | S      | S      |  |
| Maple Syrup              | S      |        |         | Peanut oil                             | S      | S      |  |
| Mayonnaise               | S      |        |         | Perchloroethylene                      | U      | U      |  |
| Mercuric chloride        | S      | S      |         | Phenol (10%)                           | S      | S      |  |
| Mercuric cyanide         | S      | S      |         | Phosgene (gas)                         | U      | U      |  |
| Mercuric nitrate         | S      | S      |         | Phosgene (liquid)                      | U      | U      |  |
| Mercurochrome            | S      |        |         | Phosphoric acid (30%)                  | S      | S      |  |
| Mercury                  | S      | S      |         | Phosphoric (85%)                       | S      | S      |  |
| Merthiolate (tincture)   | S      | S      |         | Phosphorus                             | S      |        |  |
| Methane                  | S      | S      |         | Phthalic acid                          | S      |        |  |
| Methanol                 | S      | S      |         | Picric Acid                            | S      |        |  |
| Methyl cellosolve        | S      | J      |         | Polyvinyl acetate                      | S      |        |  |
| ·                        | U      |        |         | Potassium bromide                      |        | S      |  |
| Methyl chloride          |        | 0      |         | Potassium promide  Potassium carbonate | S      | S      |  |
| Methylene chloride       | S      | 0      |         |  | S      | S      |  |
| Methyl ethyl ketone      | S      | S      |         | Potassium chlorate                     | S      | S      |  |
| Methyl isobutyl ketone   | S      | S      |         | Potassium cyanide                      | S      | S      |  |
| Methylsulfuric acid      | S      | S      |         | Potassium dichromate                   | S      | S      |  |
| Milk                     | S      | S      |         | Potassium ferrocyanide                 | S      | S      |  |
| Mineral oil              | S      | U      |         | Potassium hydroxide                    | S      | S      |  |
| Molasses                 | S      |        |         | Potassium nitrate                      | S      | S      |  |

Legend: S = Satisfactory O = Some attack U = Unsatisfactory 3 of 5



| Potassium permanganate     | S |   |                                       |            |
|----------------------------|---|---|---------------------------------------|------------|
|                            | _ | 0 |                                       | Reagent    |
| Potassium sulfate          | S | S | S                                     | T          |
| Potassium sulfide          | S | S | S                                     | Tannic ad  |
| Propanol                   | S | S |                                       | Tartaric A |
| Pyridine                   | S |   |                                       | Tea        |
| R                          |   |   |                                       | Tetrahydı  |
| Rice Bran Oil              | S | S |                                       | Tetralin   |
| Rosin, light               | S |   |                                       | Toluene    |
| S                          |   |   |                                       | Tomato J   |
| Safflower Oil              | S | 0 |                                       | Tomato S   |
| Sauerkraut                 | S |   |                                       | Tributyl p |
| Shellac                    | S |   |                                       | Trichloroa |
| Silicone Oil               | S |   |                                       | Trichloroe |
| Silver cyanide             | S | S |                                       | Tricresyl  |
| Silver nitrate             | S | S | S                                     | Triethand  |
| Sodium acetate             | S | S |                                       | Trisodium  |
| Sodium benzoate            | S | S | S                                     | Turpentin  |
| Sodium bicarbonate         | S | S |                                       | U          |
| Sodium bisulfate           | S | S | ,                                     | Urea       |
| Sodium bisulfite           | S | S |                                       | Urine      |
| Sodium bromide             | S | S |                                       | V          |
| Sodium carbonate           | S | S | S                                     | Vanilla    |
| Sodium chlorate            | S | S | 0                                     | Varnish    |
| Sodium chloride            | S | S | 0                                     | Vaseline   |
| Sodium cyanide             | S | S |                                       | Vinegar    |
| Sodium hydroxide, conc.    | S | S | S                                     | W          |
| Sodium Hypochlorite, conc. | S | 0 | U                                     | Water      |
| Sodium Nitrate             | S | S | S                                     | Wheat G    |
| Sodium Perborate           | S |   |                                       | Whiskey    |
| Sodium Phosphate           | S | S | S                                     | White Sp   |
| Sodium sulfate             | S | S |                                       | Wines      |
| Sodium sulfite             | S | S |                                       | X          |
| Sodium Thiosulfate         | S | S |                                       | Xylene     |
| Soybean Oil                | S | S |                                       | Xylol      |
| Stannic chloride           | S | S |                                       | Y          |
| Stannous chloride          | S | S | · · · · · · · · · · · · · · · · · · · | Yeast      |
| Starch                     | S | S |                                       | Z          |
| Styrene                    | U | U | U                                     | Zinc chlo  |
| Sucrose (20%)              | S | S |                                       | Zinc oxid  |
| Sulfamic acid              | S | S |                                       | Zinc sulfa |
| Sulfur                     | 0 | U | U                                     |            |
| Sulfur Chloride            | 0 | U | U                                     |            |
| Sulfuric acid (10%)        | S | S | S                                     |            |
| Sulfuric acid (50%)        | S | S | =                                     |            |
| Sulfuric acid, conc.       | S | 0 | U                                     |            |
| Sulfuric acid (fuming)     | U | U | <u></u>                               |            |

| Reagent              | 70°F<br>(21°C) | 140°F<br>(60°C) | 212°F<br>(100°C) |
|----------------------|----------------|-----------------|------------------|
| Т                    |                |                 |                  |
| Tannic acid (10%)    | S              | S               |                  |
| Tartaric Acid        | S              | S               | S                |
| Tea                  | S              | S               | S                |
| Tetrahydrofuran      | S              | S               | 0                |
| Tetralin             | 0              | 0               | 0                |
| Toluene              | U              | U               |                  |
| Tomato Juice         | S              | S               | S                |
| Tomato Soup          | S              | S               | S                |
| Tributyl phosphate   | S              | 0               |                  |
| Trichloroacetic Acid | S              | 0               |                  |
| Trichloroethylene    | U              | U               |                  |
| Tricresyl phosphate  | S              | S               |                  |
| Triethanolamine      | 0              | 0               |                  |
| Trisodium phosphate  | S              | S               |                  |
| Turpentine           | S              | 0               | 0                |
| U                    |                |                 |                  |
| Urea                 | S              | S               |                  |
| Urine                | S              | S               |                  |
| V                    |                |                 |                  |
| Vanilla              | S              | S               |                  |
| Varnish              | S              |                 |                  |
| Vaseline             | S              | 0               | 0                |
| Vinegar              | S              | S               |                  |
| W                    |                |                 |                  |
| Water                | S              | S               | 0                |
| Wheat Germ Oil       | S              | S               |                  |
| Whiskey              | S              | S               | S                |
| White Spirits        | U              | U               | U                |
| Wines                | S              | S               |                  |
| X                    |                |                 |                  |
| Xylene               | 0              | U               |                  |
| Xylol                | S              |                 |                  |
| Y                    |                |                 |                  |
| Yeast                | S              | S               |                  |
| <b>Z</b>             |                |                 |                  |
| Zinc chloride        | S              | S               |                  |
| Zinc oxide           | S              | S               |                  |
| Zinc sulfate         | S              | S               |                  |

Legend: S = Satisfactory O = Some attack U = Unsatisfactory



Note: The proceeding information concerns general chemical resistance only. Since other factors such as permeation, ESCR and container design are involved, full compatibility testing is recommended. Staining is not considered in this evaluation.

#### Product inquiries:

Marina View Headquarters 2600 South Shore Blvd. Suite 500 League City, Teas 77573 Telephone: 281-535-6600 Fax: 281-535-6764 Customer Service: 800-527-5419 Battleground Manufacturing Complex

1230 Independence Parkway South La Porte, Texas 77571 Telephone: 713-307-3000 Fax: 713-307-3521 Technical Center: 800-338-0489 www.ineos-op.com

http://ordersonline.ineos-op.com

Technical information contained herein is furnished without charge or obligation and is given and accepted at recipient's sole risk. As conditions of use may vary and are beyond the control of INEOS Olefins & Polymers USA, no representations or warranty, express or implied, are made with respect to the accuracy, reliability, or completeness of the this information. This information in no way modifies, amends, enlarges, or creates any specification or warranty, and ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY EXCLUDED. INEOS Olefins & Polymers USA shall not be responsible for any damage or injury resulting from abnormal use, from any failure to follow appropriate practices, or from hazards inherent in the nature of the product and/or material, nor for toxicological effects or Industrial Hygiene associated with particular use of any product described herein. This information relates only to the specific product and/or material designated and may not be valid for such product and/or material used in combination with any other product and/or material or in any process, unless otherwise specified. This information shall not be construed as a recommendation for any use that may infringe any patent, trademark, or the like, or as an endorsement of any material, equipment, service, or other item not supplied by INEOS Olefins & Polymers USA.

The name and logo INEOS are trademarks of the INEOS Group and its affiliated companies and businesses.

© INEOS Olefins & Polymers USA February, 2012

